

Hearing Induction Loop

– located below the Audio Mixer & Wireless Receiver

There are 3 connections only to the back of the ILD500 (which belongs to the Community Centre):

1. Standard IEC (Kettle) mains plug provides power
2. Speakon connector which goes to wire loop around Hall
3. Standard XLR microphone socket provides feed from mixer



1. Standard Mains Kettle Power input Connector

2. Speakon output connector to wire induction loop around entire Main Hall

3. XLR microphone socket input



The XLR microphone socket is driven by a low level signal from the audio mixer where a mono jack is plugged into 'CTRL ROOM OUT' (The cable consists of a mono jack plug at one end and a female XLR plug at the other end)